

Upgrading firmware

Find out the latest firmware version from Transcend website :

<http://www.transcend-info.com/Support/No-675>

Note : To prevent data loss, it is recommended that you backup your data to another location before upgrading the firmware of your DrivePro DP100.

1. After downloading firmware from Transcend website, decompress it and then put “DP100.bin” in the “SYSTEM” folder in microSD memory card.



2. Insert the microSD memory card that contains a newer version of firmware.
3. Select “**Firmware Upgrade**” from the “Settings” menu and press **OK** to start the firmware detection process. The DrivePro will automatically find the new firmware file.

